

# MacBook Core Duo Logic Board Replacement



## Step 4

- Lift up on L-shaped memory cover, slide it to the right, and lift it out of the computer.



## Step 5 Upper Case

- Remove the following 3 screws:
  - One 11 mm Phillips in the middle of the case.
  - Two 14.5 mm Phillips.
- If the screws stick in the case, you can use a magnetized screwdriver to draw them out.
- The shorter of the three screws goes in the middle.



## Step 6

- Remove the following 3 screws from the rear wall of the battery compartment:
  - Two 3 mm Phillips.
  - One 4 mm Phillips on the right side.
- When reinstalling these screws, it may be helpful to push down on the lower case to line up the screw holes.