

5.20 Bluetooth Board



This section applies only to full-featured models.

Bluetooth Board Spare Part Number Information

Broadcomm Bluetooth board	376651-001
---------------------------	------------

1. Prepare the notebook for disassembly ([Section 5.3](#)) and remove the following components:
 - a. Optical drive ([Section 5.5](#))
 - b. Memory module compartment cover ([Section 5.6](#))
 - c. Mini PCI compartment cover ([Section 5.7](#))
 - d. Keyboard cover ([Section 5.8](#))
 - e. Keyboard ([Section 5.10](#))
 - f. Display assembly ([Section 5.11](#))
 - g. Base enclosure ([Section 5.12](#))
2. Turn the USB/S-Video controller board upside down with the USB port away from you.