

GENERAL INFORMATION

WIRE CLAMP

- MAIN WIRE HARNESS
- ALTERNATOR WIRE
- NEUTRAL/REVERSE SWITCH WIRE
- FINAL GEAR CASE BREATHER HOSES
- REVERSE CONTROL CABLE

CLAMP

- FINAL GEAR CASE BREATHER HOSES

WIRE CLAMP

- REVERSE CONTROL CABLE
- BATTERY NEGATIVE (-) CABLE
- ENGINE GROUND CABLE
- FINAL GEAR CASE BREATHER HOSES

WIRE CLAMP

- STARTER RELAY SWITCH-TO-STARTER MOTOR CABLE
- REVERSE CONTROL CABLE

WIRE CLAMP

- MAIN WIRE HARNESS
- STARTER RELAY SWITCH-TO-STARTER MOTOR CABLE
- BATTERY NEGATIVE (-) CABLE

